


Installation Guide



2630 - iButton or Driver ID



Fleetsupport@mifleet.us | www.mifleet.us | 1.866.643.5338 opt. 2


Device Installation:

- 1. **Connect** the device to the 5C260 wiring harness via the 20-pin connection.
- 2. From the 5C260 wiring harness, **locate** the power (red) and ground (black) that will be connected to vehicle power (12V) and ground. Then **locate** the ignition sense wire (white) which will be connected to vehicle ignition on.

3. Connect iButton Reader 4C763 then connect that to the 5C260 wiring harness through the 2-PIN mating connection. (Fig.1)

*Note: If using the optional Buzzer 4C765 to the main wire harness 5C260 using the 3-PIN connector. (Fig.2)

4. Cables are now ready to be installed into vehicle. (Fig.3)



^{*}Note: Voltage is supplied to the white wire and when Ignition is OFF Voltage is removed from the white wire.