
VT3500 Device Icons



Power:

Indicator Light **GREEN** when device has power

Indicator Light OFF (no light) when device does not have power

Troubleshooting Notes

If customer indicates that device has been installed and there is no green power indicator light, check the following:

- All device cables are connected. If connections are within reach, disconnect and reconnect.
- Vehicle has ignition turned on. When ignition is on, give the device a minute to power up.

Event:

Indicator light will flash **RED** when an event occurs

- This is not commonly an icon used for device troubleshooting.
- Blinks RED three times when event occurs.

GPS Status:

Indicator Light OFF (no light) when device has GPS positioning and functioning normally

Indicator Light **RED** when GPS error detected, positioning abnormal

If the indicator light is **RED** consistently:

- Check location devices and ensure there are no other devices that could be blocking signal
- Check SIM management portal for SIM activity
- Ensure vehicle is not in a building or covered area that might prevent network connection

If indicator light is **RED** <u>periodically</u> but device is reporting properly, no troubleshooting required, intermittent coverage with store and forward of data is common and handled by system

Network Status:

Indicator Light OFF (no light) when network connectivity is normal

Indicator Light RED when there network connectivity error is detected

If the indicator light is RED consistently:

- Check SIM management portal for SIM activity
- Check SIM management portal for network outage notification
- Ensure vehicle is not in a building or covered area that might prevent network connection If indicator light is **RED** <u>periodically</u> but device is reporting properly, no troubleshooting required, intermittent coverage with store and forward of data is common and handled by system

Forward Facing Camera:

Indicator Light **OFF** (no light) when forward (road) facing camera is recording properly
Indicator Light **RED** when error is detected with forward (road) facing camera recording

<u>Troubleshooting Notes</u>

If the indicator light is **RED** consistently:

- Confirm device connections
- Confirm camera lens is not obstructed
- Confirm in platform if recordings are available for this channel

Driver Facing Camera:

Indicator Light **OFF** (no light) when driver facing camera is recording properly

Indicator Light **RED** when error is detected with driver facing camera recording <u>Troubleshooting Notes</u>

If the indicator light is **RED** consistently:

- Confirm device connections
- Confirm camera lens is not obstructed
- Confirm in platform if recordings are available for this channel

Extension Camera:

Indicator Light **OFF** (no light) when extension (accessory) camera is recording properly Indicator Light **RED** when error is detected with extension (accessory) camera recording